

INSTALLATION, USER AND MAINTENANCE MANUAL FOR WATER OSMOSIS UNIT



WO-01



EQUIPMENT FOR POTABLE WATER TREATMENT

CONTENTS:

| | |
|--|-----------|
| GENERAL WARNINGS..... | Paragraph |
| TECHNICAL CHARACTERISTICS | |
| POSITIONING AND INSTALLATION | |
| MAINTENANCE | |
| PLUMBING DIAGRAM | |
| WIRING DIAGRAM | |
| FAULTS | |
| ELECTRONIC CIRCUIT BOARD AND PROGRAMMING | |
| EXPLODED VIEWS | |
| LIST..... | |

TECHNICAL INSTRUCTIONS:



These are intended for the qualified staff who are to install, commission and test the appliance and carry out any servicing and repairs.

USER INSTRUCTIONS:



These provide recommendations for use, a description of the controls and the correct procedures for cleaning and maintaining the Osmosis Treatment Unit.

WARNINGS:



Warnings regarding operations which are prohibited inasmuch as they can result in injury or damage.



THIS MANUAL IS AN INTEGRAL PART OF THE OSMOSIS TREATMENT UNIT; KEEP IT CAREFULLY IN THE VICINITY OF THE MACHINE AND READ THE INSTALLATION AND USER INSTRUCTIONS CONTAINED IN IT.

1. General warnings



STORAGE:

THE PACKED APPLIANCE MUST BE STORED IN A DRY, CONDENSATION-FREE AREA, UNDER COVER. THE ADMITTED STORAGE TEMPERATURE IS 4-50°C.



ALWAYS DISCONNECT ELECTRICAL POWER BEFORE WORKING ON THE APPLIANCE OR DISASSEMBLING IT.



POSITIONING, HOOKUP, COMMISSIONING, TROUBLESHOOTING AND REPLACING POWER CABLES **MUST ALWAYS BE DONE BY QUALIFIED PERSONS**.



CHANGES IN THE POWER VOLTAGE OF MORE THAN 10% OF THE RATED VALUE CAN DAMAGE THE ELECTRICAL CIRCUITS; MONITOR THE MAINS VOLTAGE CONSTANTLY.



THE APPLIANCE MUST BE GROUNDED AS REQUIRED BY ELECTRICAL EQUIPMENT SAFETY STANDARDS.



THIS UNIT **IS INTENDED ONLY** FOR THE INTENDED PURPOSE OF **TREATING WATER FOR TECHNICAL PURPOSES**.



SHIPPING/DELIVERY:

THERE ARE NO SPECIAL PRECAUTIONS FOR UNPACKING THE APPLIANCE, EXCEPT FOR THE NORMAL CARE REQUIRED IN HANDLING FRAGILE MATERIALS. BEFORE DISPOSING OF THE PACKAGING, MAKE SURE IT DOES NOT CONTAIN ANY PARTS, INSTRUCTION BOOKLET OR OTHER DOCUMENTATION.



THE PACKAGING (CARDBOARD, EXPANDED POLYSTYRENE, PALLET, ETC.) **MUST NOT BE LEFT WITHIN THE REACH OF CHILDREN**, SINCE THEY ARE HAZARDOUS MATERIALS.



THE OSMOSIS TREATMENT UNIT MAY BE **REMOVED FROM ITS ORIGINAL POSITION** ONLY BY **SPECIALISED PERSONS**.



WHEN CLEANING THE APPLIANCE **DO NOT USE** CORROSIVE PRODUCTS, ACIDS, STEEL PADS OR BRUSHES.




DO NOT WASH THE APPLIANCE WITH DIRECT OR HIGH PRESSURE JETS OF WATER.



THE MANUFACTURER **DECLINES ALL LIABILITY** FOR INJURY/DAMAGE TO PERSONS OR PROPERTY **CAUSED BY NON-OBSERVANCE** OF THE INSTRUCTIONS GIVEN IN THIS MANUAL, **INCORRECT USE, TAMPERING BY UNQUALIFIED PERSONS, TAMPERING** WITH EVEN ONE PART OF THE APPLIANCE, OR THE USE OF **NON-ORIGINAL SPARE PARTS**, OR MODIFICATIONS, ACCESSORIES OR DEVICES OF ANY KIND APPLIED TO THE APPLIANCE UNLESS EXPRESSLY SPECIFIED IN THIS MANUAL.



THIS APPLIANCE IS MARKED AS REQUIRED BY EU DIRECTIVE **2002/96/EC**, WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEE).
BY MAKING SURE THAT THIS PRODUCT IS DISPOSED OF CORRECTLY THE USER HELPS TO PREVENT POTENTIAL DETRIMENTAL EFFECTS ON HEALTH AND THE ENVIRONMENT.

THE SYMBOL  ON THE PRODUCT OR IN THE TECHNICAL DOCUMENTATION INDICATES THAT THIS PRODUCT MUST NOT BE TREATED AS ORDINARY DOMESTIC WASTE BUT MUST BE CONSIGNED TO THE SPECIAL COLLECTION POINT FOR THE RECYCLING OF ELECTRICAL AND ELECTRONIC EQUIPMENT.
WHEN DECOMMISSIONING THE APPLIANCE COMPLY WITH THE LOCAL WASTE DISPOSAL REGULATIONS.

FOR FURTHER INFORMATION ON THE TREATMENT, RECOVERY AND RECYCLING OF THIS PRODUCT, CONTACT THE COMPETENT LOCAL OFFICE, THE DOMESTIC WASTE COLLECTION SERVICE, OR THE SHOP WHERE THE PRODUCT WAS PURCHASED.



FOR ANY TECHNICAL OR OPERATIONAL INFORMATION, PLEASE CONTACT OUR **TECHNICAL SERVICE DEPARTMENT**.



IMPORTANT:

DURING THE WARRANTY PERIOD **THE MACHINE MAY NOT BE WORKED ON WITHOUT ADVANCE AUTHORISATION** FROM OUR TECHNICAL SERVICE DEPARTMENT. FAILURE TO ABIDE BY THIS RULE VOIDS THE WARRANTY.

2. Technical characteristics

GENERAL DESCRIPTION:




THE APPLIANCE PRODUCES OSMOSIS- TREATED WATER, WITHOUT DISSOLVED SALTS, WITH A RESIDUAL CONDUCTIVITY IN THE RANGE 20 TO 100 MICROSIEMENS, INTENDED **EXCLUSIVELY** FOR TECHNOLOGICAL APPLICATIONS. THE UNIT CONSISTS OF AN ARRAY OF FILTER CARTRIDGES. THE INVERSE OSMOSIS MEMBRANES ARE LODGED IN POLYPROPYLENE HOUSINGS. THE OSMOSIS PUMP IS CONSTRUCTED IN BRASS

| Dimensions | | | | | |
|------------|-----|----|----------------------------------|----|----|
| Height | 814 | mm | Empty weight | 60 | kg |
| Width | 376 | mm | Empty weight including packaging | 67 | kg |
| Depth | 600 | mm | | | |

| Installation characteristics | | | | | |
|------------------------------|------------------|--------|----------------------------------|-----|--------|
| Power cable | 3x1 length 1.5 m | | Diameter of waste discharge pipe | 4 | mm |
| Plug | Schuko | | Length of waste discharge pipe | 1.5 | m |
| Length of filler pipe | 1.5 | m | Delivery fitting | 3/4 | inches |
| Filler pipe collar | 3/4 | inches | | | |

| Technical characteristics | | |
|-----------------------------------|--------------------|--------------|
| Single phase power voltage | 230 | v |
| Frequency | 50 | Hz |
| Osmosis pump power rating | 450 | w |
| Delivery pump power rating | 300 | w |
| Min/max water supply pressure | 150-600 (1.5-6) | kPa (bar) |
| Max osmosis-treated water output | 150 | l/h |
| Max water supply temperature | 30 | °C |
| Max water supply hardness | 40 | °F |
| Max water supply conductivity | 2.000 | µS/cm |
| Max water supply chlorine content | <0.1 | mg/l |
| Max water supply iron content | <0.02 | mg/l |
| Min/max delivery pump pressure | 0.5-1.8 | Bar |
| Max delivery pump output | 20 | l / h |



3. Positioning and installation



THE APPLIANCE **MUST BE CONSIDERED AND HANDLED AS FRAGILE MATERIAL.**



THE CIRCUIT DOWNSTREAM OF THE UNIT MUST BE CONSTRUCTED IN PLASTIC AND STAINLESS STEEL TO PREVENT CORROSION.



IF THE WATER SUPPLY CONTAINS PARTICLES IN SUSPENSION, AN EXTERNAL FILTER MUST BE INSTALLED TO PROVIDE SUFFICIENT DOWNSTREAM FLOW AND PRESSURE ; THIS FILTER MUST BE KEPT IN PERFECT CONDITION AT ALL TIMES .

Positioning:

Before installing the appliance, check that there is sufficient clearance for easy extraction of consumables and for servicing the unit. Check that there is a power socket in the vicinity of the unit. The appliance is designed for installation in clean area, protected from freezing temperatures.

Before installation, check:

- that there is sufficient space for the plumbing
- that there is good access for equipment, inspections and maintenance

Electrical hookup:

Make sure the power supply is adequate to the unit's draw.

Caution: the power voltage rating is given on the unit's dataplate.

WARNING: Do not open the unit's electrical panel ; only qualified persons may do this.

Plumbing hookup:

Hook the machine up as indicated on the unit itself, "**IN**" indicates the water supply inlet, "**OUT**" indicates the osmosi-treated water outlet, **RJ** indicates the discharge outlet. Remove the red cap "T" from the **RJ** fitting and insert the water drain pipe supplied with the unit.

Apply the supplied pipe to the **OUT** fitting and equip its free end with a corrosion-proof cock if it is not hooked up directly to the service.

The water supply pressure may not exceed **6 bar** nor be less than **1.5 bar**.




WHEN FIRST RUNNING THE UNIT AND AFTER ANY SERVICE, RUN THE WATER DELIVERY TO A DRAIN FOR AT LEAST 20 MINUTES SO AS TO ELIMINATE ANY IMPURITIES RESULTING FROM THE WORK JUST DONE

All quick fittings are of the type

John Guest

Water circuit and electrical hookup diagram



Installing the membranes

Open the front door to access the membrane housings, which must be kept in their original packaging until the machine is started up


Disconnect
the quick coupling
hoses

Undo
the base

Fit
the membrane

Screw on
the base

Reconnect
the hoses




Pressurizing and starting up the unit:

After all pipes have been connected, pressurise the system gradually and check for leaks. Turn the "Osmosis pump" switch to "I". Check that the following message displays:

*RJ.....LT/H RR...%
..... US/CM*

In normal operation the value **Rj** varies during osmosis-treated water production.

Wait **5-10 minutes**, then continue by starting up the delivery pump.



Osmosis pump switch


IMPORTANT!!!

Delivery pump startup (first startup)

Remove the red bleeder cap **P** ("Sfiato innesco") on the front (close to the pressure gauge, labelled as such) .

To remove the cap, press the John Guest clip and allow a bit of water to run into a container; refit the cap **P**, and actuate the "Delivery pump" switch.

FAILURE TO FOLLOW THIS PROCEDURE TO THE LETTER CAN CAUSE SERIOUS DAMAGE TO THE DELIVERY PUMP.




Delivery pump switch Cap "P"

4. Maintenance

The osmosis treatment unit runs completely automatically and maintenance is minimal. The only essential operation is periodic replacement of the filter cartridges.

IMPORTANT

Replace the pre-filter every 3000 hours of operation and **AT LEAST 1 time a year**.




Pre-filter

Membrane

Replacing the pre-filter:

Filter cartridge replacement procedure


- Shut off power;
- Close the side cocks (RL);
- Vent the circuit from the top cap (S);
- Unscrew the filter housing (use the special wrench supplied in the accessories bag). Place a container to drain the water in the filter into;
- Fit the new cartridge and check it is correctly seated;
- Close vent **S** and open the side cocks **RL**;
- Check for leaks and water in the bottom of the appliance;
- Dry it off thoroughly.



Replacing the membranes:

Cartridge replacement procedure.

- Shut off power;
- Disconnect all hoses from the membrane housings, unscrew the base, and place a container to catch the water contained in the cartridges;
- Refit the membrane, check the seating of the o-ring and screw the housing fully in; reconnect the hoses and make sure they are correctly seated;
- Do not apply excessive force;
- Fit the new cartridge and check it is correctly seated;
- Start the unit up and check for leaks.



Special adjustments:

RECIRCULATION

Recirculation retreats the waste water to reduce the amount of water rejected. Turn the needle valve "Recirculation" to retreat the waste water, thus reducing overall water consumption.

Important!


Make sure, when making adjustments, that the pressure gauge reading never exceeds 10-11 bar.

BYPASS

Turn the "Bypass" needle valve to adjust the conductivity of the osmosis-treated water, at the expense of the hourly water production and the amount of water rejected.


NOTE:

In both cases, before setting the needle valves you must slacken off their collars and tighten them down after the adjustment has been made.



Recirculation

Bypass




Inactivity:

There are no special warnings regarding maintaining the appliance's operability when kept inactive for short periods of time.

For **long periods of inactivity** contact your local **Authorised Reseller** so that he can remove and store the inverse osmosis membranes **and also restart** the unit after recommissioning as for the first installation.

5. Plumbing diagram




LEGEND HYDRAULIC DIAGRAM

| | | | |
|----------------|-----------------------------|----------------|----------------------------------|
| IN | Water inlet | F ₁ | Product flow meter |
| E ₁ | Filler solenoid valve | P ₂ | Delivery minimum pressure switch |
| P ₁ | Filler pressure switch | R | Vat cock |
| FIL | Filter - CARBONLOK 5 micron | M2 | Delivery pump |
| M1 | Osmosis pump | F ₂ | Waste flow meter |
| S _R | "Re-treatment" needle valve | E ₂ | Discharge solenoid valve |
| VR | Non-return valve | SS | Discharge choke |
| MP | Pump pressure gauge | VE | Expansion tank |
| S _M | Mixer needle valve | P ₃ | Delivery pressure switch |
| MO | Osmosis membrane | SC | Water discarded |
| CO | Conductivity meter | PR | Produced water |

LEGEND ELECTRIC DIAGRAM

| | | | |
|----------------|----------------------------------|----------------|--------------------------|
| SA | Anti flooding sensor | IO | Osmosis switch |
| CO | Conductivity meter | E ₁ | Filler solenoid valve |
| LR | Red led | E ₂ | Discharge solenoid valve |
| LV | Green led | M1 | Osmosis pump |
| SE | Electronic board | LB | Low level switch |
| M2 | Delivery pump | LA | High level switch |
| P ₃ | Delivery pressure switch | PB | Low pressure switch |
| P ₂ | Delivery minimum pressure switch | F ₂ | Waste flow meter |
| SS | Shuko plug | SE | Selector |
| IR | Delivery switch | F ₁ | Product flow meter |

6. Wiring diagram



Electrical specifications:

Power supply: 230v AC 50/60Hz

Max motor outlet load: 16A_ at 230V AC

Max load on solenoid valve 1 outlet: 1A_ at 230v AC

Max load on solenoid valve 2 outlet: 1A_ at 230V AC


Instrumentation:

Conductivity meter (normalised at 20°C) scale: 0-200uS/cm with probe

K=5. Class (overall): 1

Calibrated by samples. Switchable display of uS/cm and mg/l; simply press the down button during operation.


Flow meter: pulses/l given by sensor: programmable (to account for laminar and lamellar water flow). Just one flow meter is provided, which can be switched to read a second flow (simultaneous reading: not possible).



Inputs: high level, low level, flow meter switch, minimum pressure switch: inputs receive only voltage-free contacts. Caution: do not route these cable together with power or other loads (duct them separately).

6- Faults

Front door leds



Green

Red

The door has two leds to indicate:

- Green: power on, normal operation;
- Red: fault, production of osmosis-treated water stopped

Important:
THE DOOR GIVES NO INDICATION OF DELIVERY CIRCUIT FAULTS
See below for details.

List of faults

A) No osmosis-treated water delivery

| Possible causes | Subcause | Solution | Display alarm message |
|--|---|---|-----------------------|
| Delivery pump not running | No water in vat | See point "B" | see point "B" |
| | No electrical power | Check power supply and power switch ON (see "Positioning and installation") Power plug not inserted in electrical panel (insert) | none |
| | No power to pump | Check connections and whether board is sending a signal Pump condenser faulty (replace) | |
| | Vat pressure switch faulty (jammed on empty) | Empty vat (manually with jumper on delivery pump or cock –fig.4) and replace pressure switch (fig.1) | |
| | Delivery pressure switch faulty (jammed on full) | Replace, or adjust the pressure with the adjuster screw (fig.2) | |
| | Non-return valve jammed (does not open) | Check valve, if jammed replace/clean (fig.3) | |
| | Vat not full enough for use (min level) | Wait for a few minutes while it fills | |
| | No water arriving at pump: vat suction pipe blocked/crimped/cock closed | Remove obstacle/open cock (fig.4) | |
| Delivery pump runs but does not deliver or only insufficiently | Air in delivery pipe | Shake pipe and see if air rises into the vat | none |
| | Impeller damaged/broken | Replace | |
| | The user requires minimum intake pressure of >1.8 BAR | System limit | |
| | The user requires flow > 20 l/min | Reduce user load | |
| | | | |


B) Osmosis-treated water not produced




| Possible causes | Subcause | Solution | Display alarm message |
|---|--|--|-----------------------|
| Osmosis pump not running | No electrical power | Check power supply and power switch ON (see "Positioning and installation") | none |
| | | Power plug not inserted in electrical panel (insert) | |
| | No power to pump | Check connections and whether board is sending a signal | |
| | | Pump condenser faulty (replace) | |
| | Intake pressure switch faulty (jammed on full) | Replace, or adjust the pressure with the adjuster screw (fig.5) | |
| | Vat level switch (low) faulty (jammed on full) | Max level switch faulty, does not send production enable signal (replace/clean) (see wiring diagram) | |
| | No water supply or supply pressure/flow inadequate | <ul style="list-style-type: none"> - Supply cock closed OPEN; - Supply filter blocked CLEAN - Supply pressure should be > 1.5 bar - Pre-filter up/downstream cocks closed OPEN (see maintenance section) - Filter blocked – REPLACE (fig.5) - Filler solenoid valve faulty or no power – REPLACE IF FAULTY (fig.5) - Intake pressure switch faulty (jammed on empty) – REPLACE (fig.5) | Low pressure |
| | Water in vat | Vat level switch (high) faulty, does not switch to full: continues producing with overflow. REPLACE (see wiring diagram) | Flooding alarm |
| Osmosis pump running but production low | Water supply too cold (<10°) | Increase supply temperature | |
| | Pre-filter blocked | Replace pre-filter (see maintenance section) | |
| | Membranes blocked | Replace membranes (see maintenance section) | |
| | Impeller damaged/broken | Check pressure gauge reading if > 8, replace pump or impeller as required | |
| | Bypass valves need adjustment | See special adjustments section | |
| | Discharge pipe crimped | Route pipe properly | |
| | Pressure drop in vat supply hoses | Shut off power, dry thoroughly and repair leak | |

C) Water production not conforming

| Display alarm message | Cause of alarm | Solution |
|-----------------------|--|--|
| HHHH | The treated water does not conform with settings | Adjust "bypass" needle valve |
| | | Replace membranes |
| LLLL | The water production is below the set value | Replace pre-filter (see maintenance section) |
| | | Replace membranes (see maintenance section) |
| | | Adjust "bypass" needle valve |




Figures



| | |
|--|--|
|  | <p>Non-return valve</p> |
|  | <p>Vat cock</p> |
|  | <p>Pressure switch</p> <p>Solenoid valve</p> <p>Filter</p> |

7. Electronic circuit board and programming

Hold down **F1** and press **ENTER** to enter conductivity programming.



| | | | |
|---|--|---|--|
| <p>Press ENTER or F1: Stop motore se in moto per ... (Stop motor after ...) The following two messages concern the osmosis pump motor condition. Set = 0 to exclude this mode; if the value is not 0, the motor stops running after having run continuously for the set period, then starts again.</p> | | <div style="border: 1px solid black; padding: 5px;">STOP MOTORE SE IN MOTO PER</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; margin-top: 10px; display: flex; align-items: center; justify-content: center;">F1</div> | |
| <p>After two seconds, the system displays:>>>>>>>>>>>>></p> | | <div style="border: 1px solid black; padding: 5px;">SE=0 NIENTE STOP IN MOTO PER 000</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; margin-top: 10px; display: flex; align-items: center; justify-content: center;">F1</div> | |
| <p>Press ENTER or F1: If the conductivity value remains below set value, no alarm trips, otherwise an alarm displays.>>>>>>>>>>>>>>>>>>></p> | | <div style="border: 1px solid black; padding: 5px;">SETPOINT CONduc. 100 US/cm</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; margin-top: 10px; display: flex; align-items: center; justify-content: center;">F1</div> | |
| <p>Press ENTER or F1: Set number of pulses per litre for the product flow meter.>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>></p> | | <div style="border: 1px solid black; padding: 5px;">IMPOSTAZIONE PR. IMPULSI/LT.0100</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; margin-top: 10px; display: flex; align-items: center; justify-content: center;">F1</div> | |
| <p>Press ENTER or F1: Set number of pulses per litre for the waste flow meter.>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>></p> | | <div style="border: 1px solid black; padding: 5px;">IMPOSTAZIONE RG. IMPULSI/LT.0100</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; margin-top: 10px; display: flex; align-items: center; justify-content: center;">F1</div> | |
| <p>Press ENTER or F1: Set minimum production below which a fault is reported.>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>></p> | | <div style="border: 1px solid black; padding: 5px;">IMPOST. LOW PR. SETPOINTO 60LT/H</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; margin-top: 10px; display: flex; align-items: center; justify-content: center;">F1</div> | |

Press **ENTER** or **F1**:
 Stop motore se in moto per ... (Stop motor after ...)
 The following two messages concern the osmosis pump
 motor condition. Set = **0** to exclude this mode; if the value
 is not 0, the motor stops running after having run
 continuously for the set period, then starts again.

ENT

STOP MOTORE SE
IN MOTO PER

F1

After two seconds, the system displays:>>>>>>>>>>

ENT

SE=0 NIENTE STOP
IN MOTO PER 000

F1

Press **ENTER** or **F1**:
If the conductivity value remains below set value, no alarm trips, otherwise an alarm displays.>>>>>>>>>>>>>>>>

Figure 10 shows the "SETPOINT CONDUCT." screen. The display shows "SETPOINT CONDUCT." and "100 US/CM". The navigation buttons are ENT, F1, and up/down arrows.

[illegible]

Diagram illustrating the control panel layout for the initial setup:

- Top left: **ENT** button.
- Center: Display showing **IMPOSTAZIONE PR. IMPULSI/LT.0100**.
- Top right: Up and Down arrow buttons.
- Bottom left: **F1** button.

[illegible]

Diagram illustrating the control panel layout for the "IMPOSTAZIONE RG. IMPULSI/LT.0100" setting. The panel includes an "ENT" button, a display showing "IMPOSTAZIONE RG. IMPULSI/LT.0100", and an "F1" button.

[illegible]

ENT

IMPOST. LOW PR.
SETPOINTO 60LT/H

▲
▼

F1

Press **ENTER** or **F1**; the system returns to standby.

| | |
|---|---|
| <p>The switch at the top of the display, if pressed to the right, switches from the waste water flow display</p> | <p>to the osmosis-treated water flow display. When it is released, the display returns to waste water flow mode.</p> |
| <div data-bbox="197 488 775 555"></div> <div data-bbox="197 609 775 1003"><div data-bbox="316 654 379 712">ENT</div><div data-bbox="279 745 638 869"><div data-bbox="300 768 619 813">RJ.....LT/H RR...%</div><div data-bbox="300 813 478 857">..... US/CM</div></div><div data-bbox="646 734 699 790">▲</div><div data-bbox="646 801 699 857">▼</div><div data-bbox="316 902 379 958">F1</div></div> | <div data-bbox="874 398 1452 555"></div> <div data-bbox="874 609 1452 1003"><div data-bbox="992 654 1056 712">ENT</div><div data-bbox="957 745 1316 869"><div data-bbox="978 768 1281 813">PRODUCT:.....LT/H</div><div data-bbox="978 813 1157 857">..... US/CM</div></div><div data-bbox="1324 734 1377 790">▲</div><div data-bbox="1324 801 1377 857">▼</div><div data-bbox="992 902 1056 958">F1</div></div> |